

cat. 9152026
 tel. 7106-68-

ID 974

electronic controllers for “forced air” refrigeration units



USER INTERFACE

The user has a display and four keys for controlling status and programming of the instrument.

KEYS AND MENUS

UP key		Scrolls through the menu items Increases the values Activates manual def. function
DOWN key		Scrolls through the menu items Decreases the values Programmable by parameter
fnc key		ESC function (exit) Programmable by parameter
set key		Accesses the setpoint Accesses the menus Confirms the commands Displaying the alarms (if present)

At start-up the instrument performs a Lamp Test; for few seconds the display and the leds blink, in order to verify their integrity and correct operation. The instrument has two main menus: the “Machine Status” and “Programming” menu.

ACCESSING AND USING MENUS

Resources are arranged in a menu, which can be accessed by pressing and quickly releasing the “set” key (“Machine Status” menu) or by holding down the “set” key for more than 5 seconds (“Programming” menu). To access the contents of each folder, indicated by the relevant label, just press the “set” key once. You can now scroll through the contents of each folder, modify it or use its functions. If you do not use the keyboard for over 15 seconds (time-out) or if you press the “fnc” key once, the last value shown on the display is confirmed and you return to the previous screen mask.

LED		
Position	Related Function	Status
	Compressor or relay 1	ON when the compressor is started up; blinking in case of delay, protection or blocked enabling
	Defrost	ON when defrosting; blinking in case of manual enabling
	Alarm	ON when the alarm is enabled; blinking when the alarm is silenced
	Fans	ON when the fan is working

TECHNICAL DATA

ALL MODELS
Frontal panel protection: IP65.
Casing: plastic body in resin type PC+ABS UL94 V-0, inspection window in polycarbonate, buttons in thermoplastic resin.
Dimensions: frontal panel 74x32 mm, depth 60 mm (**depth 68 mm only for ID 974 switching**).
Installation: on panel, with drilling template 71x29 mm (+0.2/-0.1 mm).
Use temperature: -5...55 °C.
Storage temperature.: -30...85 °C.
Use and storage environment humidity: 10...90 % RH (not condensing).
Viewing range:
• NTC probe: -50...110 °C (-58...230°F)
• PTC probe: -55...140 °C (-67...284°F)
without decimal point (selectable through parameter on 3 digit + 1/2 mark display.
Analog inputs: two PTC or NTC inputs (programmable by parameter).
Serial: TTL for connection to Copy Card or Televis system.
Digital outputs: 3 relay contacts: first contact SPDT 8(3)A 250V~, second contact SPST 8(3)A 250V~, third contact SPST 5(2) A 250V~.
Measuring range: from -55 to 140 °C.
Accuracy: 0.5% better than end scale + 1 digit.
Resolution: 1 or 0.1 °C.
Consumption
• model 230V: 3 VA max.
• model 12V: 1,5 VA max.
• model with switching Power Supply: 3W
Power supply: 12 V~/= ±10% or 230V~ ±10% 50/60 Hz.

MODEL 8+8+15A
Digital outputs: 3 relay contacts:
• (A) SPDT 8(3)A (1/2 Hp) 250V~,
• (B) SPST 8(3)A (1/2 Hp) 250V~,
• (C) SPST 15A (1 Hp) 250V~.
Consumption: 1,5 VA max.
Power supply: 12 V~/= ±10%.

MODEL 8+8+15A + D.I.
Digital input
1 voltage-free digital input that can be set by parameter.
MODEL with Switching power supply
Digital outputs: 3 relay contacts:
• (A) first contact SPDT 8A 250V~,
• (B) second contact SPST 3A 250V~,

MACHINE STATUS MENU

To access the “Machine Status” menu Press and quickly release the “set” key. If alarms are not present, the label “SEt” appears. By using the “UP” and “DOWN” keys you can scroll through the other folders in the menu:
-Pb1: probe 1 value folder;
-Pb2: probe 2 value folder
-SEt: Setpoint setting folder.
Set Setting
Access the “Machine Status” menu by pressing and quickly releasing the “set” key. The label of the “SEt” folder appears. To display the Setpoint value press the “set” key again. The value appears on the display. To change the Setpoint value, use the “UP” and “DOWN” keys within 15 seconds. If the parameter is LOC = y the Setpoint cannot be changed.
Alarm on
If alarm condition exists, when accessing The “Machine Status” menu the “AL” folder label appears (see the “Diagnostics” section).
Displaying Probes
By pressing the “set” key when the appropriate label appears, the value of the probe associated to it is displayed.

PROGRAMMING MENU

To enter the “Programming” menu, press the “set” key for more than 5 seconds. If specified, the access PASSWORD will be requested, (parameter “PA1”), and the label of the first folder will follow. To scroll through the other folders, use the “UP” and “DOWN” keys. To enter the folder, press “set”. The label of the first visible parameter appears. To scroll through the other parameters, use the “UP” and “DOWN” keys; to change the parameter, press and release “set”, then set the desired value using the “UP” and

“DOWN” keys, and confirm with the “set” key to move to the next parameter.

PASSWORD

The password allows access to programming parameters. In the standard configuration password is not present. To enable and assign it the desired value, access the “Programming” menu, within the folder with the “diS” label. If password is enabled, you will see it at the entrance of the “Programming” menu.

MANUAL ACTIVATION OF THE DEFROSTING CYCLE
To manually activate the defrosting cycle, press the “UP” key for 5 seconds. If defrosting conditions are not present, (for example the evaporator probe temperature is higher than defrost stop temperature), the display will blink three (3) times, in order to indicate that the operation will not be performed.

COPY CARD

The Copy Card is an accessory connected to the TTL serial port which allows programming quickly the instrument parameters. The operation is performed as follows:

Fr-Format

This command allows copy card formatting, an operation recommended in case of first use. Warning: if the copy card has been programmed, using the “Fr” the data entered are erased. This operation cannot be cancelled.

UL-Upload

This operation loads the programming parameters from the instrument.

dL-Download

This operation downloads to the instrument the programming parameters. The operations are performed accessing the folder identified by the “FPr” label and selecting, according to the case, “UL”, “dL” or “Fr” commands; the operation is confirmed by pressing the “set” key. If the operation is successful an “y” is displayed, on the contrary, if it fails a “n” will be displayed.

PLEASE NOTE: The technical data included in this document, related to measurement (range, accuracy, resolution, etc.) refer to the instrument itself, and not to its equipment such as, for example, sensors. This means, for example, that sensor(s) error(s) shall be added to the instrument’s one.

LIABILITY AND RESIDUAL RISKS

Eliwell Controls s.r.l. shall not be liable for any damages deriving from:
- installation/use other than that prescribed and, in particular, that which does not comply with safety standards anticipated by regulations and/or those given herein;
- use on boards which do not guarantee adequate protection against electric shock, water or dust under the conditions of assembly applied;
- use on boards which allow access to dangerous parts without the use of tools;
- tampering with and/or alteration of the products;
- installation/use on boards that do not comply with the standards and regulations in force.

DISCLAIMER

This manual and its contents remain the sole property of Eliwell Controls s.r.l., and shall not be reproduced or distributed without authorization. Although great care has been exercised in the preparation of this document, Eliwell Controls s.r.l., its employees or its vendors, cannot accept any liability whatsoever connected with its use. Eliwell Controls s.r.l. reserves the right to make any changes or improvements without prior notice.

Duty Cycle Diagram		
Ont, OFt parameters programmed for Duty Cycle		
Ont	OFt	Output compressor
0	0	OFF
0	>0	OFF
>0	0	ON
>0	>0	dc

When the sensor detects an error condition:

- the code E1 is displayed
- the regulator is activated as indicated by the "Ont" and "OFt" parameters if programmed for the duty cycle or:

OUT	On	Off	
	Ont	OFt	Ont

NOTE:
• **UPLOAD: instrument —> Copy Card**
• **DOWNLOAD: Copy Card —> instrument.**

KEYBOARD LOCKING

The instrument includes a facility for disabling the keyboard, by programming the “Loc” parameter (see folder with “diS” label). If the keyboard is locked, you can still access the programming menu by pressing the “SET” key. The Setpoint can also be viewed.

DIAGNOSTICS

The alarm condition is always signalled by the buzzer (if present) and by the led of

the alarm icon (

The alarm signal produced by a faulty thermostat probe (referred to probe 1) is shown as E1 on the instrument display The alarm signal produced by a faulty evaporator probe (probe 2) is shown as E2 on the instrument display.

Probe faults table	
DISPLAY	FAULT
E1	Faulty probe 1 (thermostat)
E2	Faulty probe 2 (1st evaporator)
If simultaneous, they will be showed on the display alternately, every 2 seconds	

The error condition of the probe 1 (thermostat) causes the following:
• viewing E1 code on the display
• compressor enabling as indicated by “Ont” and “OfT” parameters, if these are programmed for duty cycle or:

Ont	OfT	Compressor output
0	0	OFF
0	>0	OFF
>0	0	ON
>0	>0	dc

The error condition of the probe 2 (evaporator) causes the following:
• viewing E2 code on the display
• end of defrost because of time-out. Other signalling alarm are not shown on the instrument display, but from the “Machine Status” menu within the “AL” folder. The signals for maximum and minimum alarms do not appear on the instrument display but are viewable on the “Machine Status” menu in the “AL” folder, with the label “AH1” or “AL1”. The regulation of the maximum and minimum temperature alarm refers to the thermostat probe. The temperature limits are defined by the parameters “HAL” (maximum alarm) and “LAL” (minimum alarm).


DISPLAY	ALARM
AH1	High temperature alarm (referred to the thermostat probe or probe 1)
AL1	Low temperature alarm (referred to the thermostat probe or probe 1)
To silence alarms press any key.	

ONLY FOR MODEL 8+8+15A + D.I.

DISPLAY	ALARM
EA	External Alarm
OPd	Open Door Alarm

INSTALLATION

The instrument is designed for panel mounting. Make a hole of 29x71 mm, insert the instrument and fix it using the brackets provided. Do not mount the instrument in humid and/or dirty places; it is suitable for use in ordinary polluted places. Ventilate the place in proximity to the instrument colling slits.



ELECTRICAL WIRING

Attention! Never work on electrical connections when the machine is switched on.

The instrument is equipped with screw terminal boards for connection of electrical cables with a diameter of 2.5 mm² (one conductor only per terminal for power connections).

For the capacity of the terminals, see the label on the instrument.

In the model ID 974 with Switching power supply only one voltage free relay output is present, on all other models on the contrary all relay outputs are voltage free..Do not exceed the maximum current allowed; in case of higher loads, use an appropriate contactor. Make sure the power supply voltage complies with the one required by the instrument.

In 12V versions the power supply must be provided by a security transformer with the protection of a delayed 250 mA fuse.

Probes have no connection polarity and can be extended using a regular bipolar cable (note that the extension of the probes affects the EMC electromagnetic compatibility of the instrument: pay extreme attention to wiring).



Probe cables, power supply cables and the TTL serial cables should be distant from power cables.

CONDITIONS OF USE

PERMITTED USE

For safety reasons the instrument must be installed and used according to the instruction provided and in particular, under normal conditions, parts bearing dangerous voltage levels must not be accessible. The device must be adequately protected from water and dust as per the application and must also only be accessible via the use of tools (with the exception of the frontlet). The device is ideally suited for use on household appliances and/or similar refrigeration equipment and has been tested with regard to the aspects concerning European reference standards on safety. It is classified as follows:
• according to its manufacture: as an automatic electronic control device to be incorporated by independent mounting;
• according to its automatic operating features: as a 1 B-type operated control type;
• as a Class A device in relation to the category and structure of the software
UNPERMITTED USE
Any other use other than that permitted is de facto prohibited. It should be noted that the relay contacts provided are of a practical type and therefore subject to fault. Any protection devices required by product standards or dictated by common sense due to obvious safety reasons should be applied externally.

MACHINE STATUS MENU DIAGRAM AND PROGRAMMING MENU DIAGRAM



Tab. 1 Parameter Table

PAR.	DESCRIPTION	RANGE	DEFAULT*	VALUE**	LEVEL***	U.M.
diF	COMPRESSOR REGULATOR (folder with “CP” label) differential. Relay compressor tripping differential. The compressor stops on reaching the Setpoint value (as indicated by the adjustment probe), and restarts at temperature value equal to the Setpoint plus the value of the differential. Note: the value 0 cannot be assumed.	0.1...30.0	2.0		1	°C/°F
HSE	Higher SET. Maximum possible setpoint value.	LSE...302	99.0		1	°C/°F
LSE	Lower SET. Minimum possible setpoint value.	-55.0...HSE	-50.0		1	°C/°F
	COMPRESSOR PROTECTIVE DEVICE (folder with “CP” label)					
Ont (1)	On time (compressor). Compressor activation time in the event of faulty probe. If set to “1” with OFt at “0” the compressor is always on, while at OFt >0 it functions always in duty cycle mode.	0...250	0		1	min
OFt (1)	OFF time (compressor). Compressor in disabled state time in the event of a faulty probe. If set to “1” with Ont at “0” the compressor is always off, while at Ont >0 it functions always in duty cycle mode.	0...250	1		1	min
dOn	delay (at) On compressor. Delay time in activating the compressor relay after switch-on of instrument	0...250	0		1	sec
dOF	delay (after power) OFF. Delay after switch off; the indicated time must elapse between switch-off of the compressor relay and the successive switch-on.	0...250	0		1	min
dbi	delay between power-on. Delay between switch-ons; the indicated time must elapse between two successive switch-ons of the compressor.	0...250	0		1	min
OdO	delay Output (from power) On. Delay time in activating the outputs after switch-on of the instrument or after a power failure.	0...250	0		1	min
	DEFROSTING REGULATOR (folder with “dEF” label)					
dtY	defrost type. Type of defrosting. 0 = electric defrost; 1 = reverse cycle defrost (hot gas); 2 = Free defrost (compressor hot).	0/1/2	0		1	flag
dit	defrost interval time. Interval between the start of two successive defrosting operations.	0...250	6h		1	hours
dCt	defrost Counting type. Selection of count mode for the defrosting interval. 0 = compressor operating hours (DIGIFROST® method); 1 = Real Time – appliance operating time; 2 = compressor stop.	0/1/2	1		1	flag
dOH	defrost Offset Hour. Start-of-defrosting delay time from start up of instrument.	0...59	0		1	min
dEt	defrost Endurance time. Defrosting time-out; determines duration of defrosting.	1...250	30min		1	min
dSt	defrost Stop temperature. Defrost stop temperature (defined by the evaporator probe).	-50.0... 150	8.0		1	°C/°F
dPO	defrost (at) Power On. Determines if at the start-up the instrument must enter defrosting (if the temperature measured by the evaporator allows this operation). y = yes; n = no.	n/y	n		1	flag
	FANS REGULATOR (folder with “Fan” label)					
FSt	Fan Stop temperature. Fan lock temperature; if the value, read by the evaporator probe, is higher than the set value, fans stop.	-50.0...150.0	2.0		1	°C/°F
FAd	Fan differential. Fan starting differential (see par. “FSt”).	1.0...50.0	2.0		1	°C/°F
Fdt	Fan delay time. Delay time in activating fans after a defrost operation.	0...250	0		1	min
dt	drainage time. Dripping time.	0...250	0		1	min
dFd	defrost Fan disable. Allows to select the evaporator probes exclusion during defrost. y = yes; n = no.	n/y	y		1	flag
FCO	Fan Compressor OFF. Allows to select compressor fans lock OFF (switched off). y = fans activated (with thermostat; based on the value read by the defrost probe, see parameter “FSt”); n = fans off; dc = not used	n/y/dc	y		1	flag
	ALARMS (folder with “AL” label)					
AFd	Alarm Fan differential. Alarm differential.	1.0...50.0	2.0		1	°C/°F
HAL	Higher ALarm. Maximum temperature alarm. Temperature value (with regard to Setpoint) which if exceeded in an upward direction triggers the activation of the alarm signal.	LAL...150.0	50.0		1	°C/°F
LAL	Lower ALarm. Minimum temperature alarm. Temperature value (with regard to Setpoint), which if exceeded in a downward direction, triggers the activation of the alarm signal.	-50.0...HAL	-50.0		1	°C/°F
PAO	Power-on Alarm Override. Alarm exclusion time after instrument switch on, after a power failure.	0...10	0		1	hours
dAO	defrost Alarm Override. Alarm exclusion time after defrost.	0...999	0		1	min
tAO	temperature Alarm Override. Temperature alarm signal delay time.	0...250	0		1	min
	DISPLAY (folder with “dis” label)					
LOC	(keyboard) LOCK. Keyboard locking. However, you can enter parameter programming modify them along with the status of this parameter in order to allow keyboard locking. y = yes; n = no	n/y	n		1	flag
PA1	PAssword 1. When enabled (value other than 0) it constitutes the access key for level 1 parameters.	0...250	0		1	num
ndt	number display type. View with decimal point. y = yes; n = no	n/y	y		1	flag
CA1	CAlibration 1. Calibration 1. Positive or negative temperature value added to the value read by probe 1.	-12.0...12.0	0		1	°C/°F
CA2	CAlibration 2. Calibration 2. Positive or negative temperature value added to the value read by probe 2.	-12.0...12.0	0		1	°C/°F
ddl	defrost display Lock. Viewing mode during defrosting. 0 = shows the temperature read by the thermostat probe; 1 = locks the reading on the temperature value read by thermostat probe when defrosting starts, and until the next time the Setpoint value is reached; 2 = displays the label “def” during defrosting, and until the next time the Setpoint value is reached.	0/1/2	1		1	flag
dfo	display read-out. Select °C or °F for displaying the temperature read by the thermostat probe. 0 = °C, 1 = °F. PLEASE NOTE: the switch between °C and °F DO NOT modify setpoint, differential, etc. (for example set=10°C become 10°F).	0/1	0		1	flag

WIRING DIAGRAMS

MODEL 12-230V~

TERMINALS

1	Common relay contact
2	N.O. defrost relay (A)
3	N.C. defrost relay (A)
4	N.O. Compressor relay output (B)
5	N.O Fan relay output (C)
6 - 7	Power supply
8 - 9	Probe 2 input (evaporator)
8 - 10	Probe 1 input (thermostat)
A	TTL input for Copy Card

NOTE: Default user settings

MODEL with RELAY 15(8)A 1 hp

TERMINALS

1	Common relay contact (15 A max)
2	N.O. Defrost relay (A)
3	N.C. Defrost relay (A)
4	N.O. Fan relay output (B)
5	N.O. Compressor relay output (C)
6 - 7	Power supply (1,5 VA max)
8 - 9	Probe 2 input (evaporator)
8 - 10	Probe 1 input (thermostat)
A	TTL input for Copy Card

NOTE: Default user settings

MODEL with SWITCHING POWER SUPPLY

TERMINALS

3 - 4	N.O. Defrost relay (A)
3 - 5	N.C. Defrost relay (A)
2 - 6	N.O. Fan relay output (B)
2 - 7	N.O. Compressor relay output (C)
8 - 9	Probe 2 input (evaporator)
8 - 10	Probe 1 input (thermostat)
1 - 2	Power Supply- 95...240V~ (3W)
A	TTL input for Copy Card

NOTE: Default user settings

PAR.	DESCRIPTION	RANGE	DEFAULT*	VALUE**	LEVEL***	U.M.
	CONFIGURATION (folder with “CnF” label)					
H00 (1)	Probe type selection. PTC or NTC. 0 = PTC; 1 = NTC.	0/1	0/1*		1	flag
H42	Evaporator probe present.	n/y	y		1	flag
reL	reRelease firmware. Device version: read only parameter.	/	/		1	/
tAb	tAb of parameters. Reserved: read only parameter.	/	/		1	/
	COPY CARD (folder with “Fpr”label)					
UL	Up load. Programming parameter transfer from instrument to Copy Card.	/	/		1	/
dL	Down load. Programming parameter transfer from Copy Card to instrument	/	/		1	/
Fr	Format. Erasing all data in the copy card.	/	/		1	/
	NOTA BENE: using “Fr” parameter (copy card formatting) the data within the copy card will be lost permanently. The operation cannot be cancelled.					
	(1) see Duty Cycle diagram.					
	* DEFAULT column: for H00 parameter default is depending on model					
	NOTE: Switch off and switch on again the instrument after changing the input type NTC/PTC (par. H00)					
	** VALUE column: to be filled manually, with customized settings (if different from the default value).					
	*** LEVEL column: indicates the level of visibility of parameters accessible by PASSWORD (see the related paragraph)					

PARAMETERS visible only in models provided with D.I. (Digital input)						
par.	description	folder	range	default	level	U.M.
OAO	Output (door) Alarm Override. Delay time for temperature alarm signalling after disabling of digital input (or door closure).	ALL	0...10	0	2	h
tdO	time out door Open. Time-out Door Open. Alarm signalling delay time for door open.	ALL	0...250	0	2	min
H11	Configurability digital inputs/polarity. 0 = disabled; ± 1 = defrosting; ± 2 = reduced set; ± 3 = not used; ± 4 = door switch; ± 5 = external alarm. Positive values: active input for on contact; negative values: active input for off contact	CnF	-5..5	0	2	flag

Only for Modbus models
For further information please refer to the ID 974 MODBUS User Manual.

par.	description	folder	range	default	level	U.M.
	COMMUNICATION (folder with “Add” label)					
dEA	device number within the family (valid values: from 0 to 14)	Add	1...14	1	1	num
FAA	device family (valid values: from 0 to 14) The value couple FAA and dEA represents the network address of the device and it is indicated in the following way: "FF.DD" (where FF=FAA and DD=dEA).	Add	1...14	0s	1	num
PtY	Modbus parity bit n=none E=Even o=odd	Add	n/E/o	n	1	num
StP	Modbus stop bit	Add	1b/2b	1b	1	num



ELIWELL CONTROLS s.r.l.
Via dell'Industria, 15 Zona Industriale Paludi
32010 Pieve d'Alpago (BL) ITALY
Telephone +39 0437 986111
Facsimile +39 0437 989066
Internet <http://www.eliwell.it>

Technical Customer Support:
Telephone +39 0437 986300
Email: techsuppelwell@invensyscontrols.com

Invensys Controls Europe
An Invensys Company

7/2006 -GB-
cod. 9IS42066

